

# Export Data

1. File ? Export HK Data
2. Update filename
3. Select directory to export to
4. Select the column delimiter
5. The "Combine Time Columns" option will output only 1 time column. By default, there is a time column per mnemonic.
6. Select the Time Source:
  - Packet Time uses the time in the mission packet header.
  - Ground Receipt Time uses the time the ground system receives the packet. This option only works if the ground system supports it.
7. Select the Time Mode to control the format of the time column:
  - Relative Time is the time in seconds from the first packet's time in the loaded archive
  - Date/Time is the time in YYYY-MM-DD HH:MM:SS format
  - Timestamp is the Unix timestamp in seconds
8. Specify the Start and End Time in YYYY-MM-DD HH:MM:SS format. The default Start and End Time will encapsulate all data in the archive.
9. Click "Add Field" to select the mnemonics to export
10. Click "Export"

---

Revision #5

Created 6 May 2022 21:54:03 by Bradley Tse

Updated 21 April 2026 12:39:14 by Bradley Tse